

Operating instructions

Battery nutrunner

DA2motion



Read the manual carefully before use!
Keep for future use!

Maschinenfabrik Wagner GmbH & Co. KG

Birrenbachshöhe 17

53804 Much

GERMANY

Telephone: +49 2245 62-0

Fax: +49 2245 62-22

Email: info@plarad.de

Internet: www.plarad.de

Translation of the original operating instructions

Mach-55253-DE, 2, en_GB

pA# 80435



Information about this manual



This manual enables the safe and efficient handling of the battery nutrunner *DA2motion* (referred to in the following as “nutrunner”).

The manual is a component of the nutrunner and must be kept in its immediate vicinity so that the user can access it at any time.

The user must have read and understood this manual prior to commencing any tasks. A basic prerequisite for ensuring that work is performed safely is compliance with all safety instructions and guidelines in this manual. In addition, the local accident prevention regulations and general safety provisions for the nutrunner’s area of application apply.

Illustrations in this manual serve to provide a basic understanding and may differ from the actual design.

Versions



This manual is valid for the following battery nutrunners and software:

- *DA2motion*
- Diagnostic and Setting Software DSS

DA2motion

DA2motion 05

DA2motion 10

Other applicable documents



The following documents must be observed in addition to this manual:

- Rating plate
- EU declaration of conformity
- Torque selection diagram
Assignment of torques to the torque levels of the nutrunner
- Technical data sheet

Copyright

This manual is protected by copyright.

The transfer of this manual to third parties, duplications of any kind and form – including excerpts – as well as the utilisation and/or communication of the manual’s contents are not permitted without the written consent of Maschinenfabrik Wagner GmbH & Co. KG, except for internal purposes. Infringements will result in liability for damages. Maschinenfabrik Wagner GmbH & Co. KG reserves the right to assert additional claims.

Maschinenfabrik Wagner GmbH & Co. KG is the copyright holder.

Further development of the manual	This manual was compiled with great care. If you notice any errors, have any questions or identify any inconsistencies, please notify us in writing. Your suggestions for improvement will help us design a user-friendly manual.
Manufacturer	Maschinenfabrik Wagner GmbH & Co. KG Birrenbachshöhe 17 53804 Much GERMANY Telephone: +49 2245 62-0 Fax: +49 2245 62-22 Email: info@plarad.de Internet: www.plarad.de
PLARAD[®] service	Information about PLARAD [®] service and authorised PLARAD [®] partners: ■ www.plarad.de



Table of contents

1	Unpacking	7
2	Getting to know the nutrunner	10
	2.1 Illustration of the nutrunner.....	10
	2.2 Brief description.....	12
	2.3 Rating plate.....	13
	2.4 Performance variables.....	13
	2.5 Nutrunner controls.....	14
	2.6 Overview of functions.....	19
	2.7 Accessories.....	20
3	Before you begin	22
	3.1 Symbols in this manual.....	22
	3.2 Symbols on the nutrunner.....	24
	3.3 Intended use.....	27
	3.4 Misuse.....	27
	3.5 General safety instructions for electric tools.....	28
	3.5.1 Workplace safety.....	29
	3.5.2 Electrical safety.....	29
	3.5.3 Personal safety.....	30
	3.5.4 Using and handling the electric tool.....	30
	3.5.5 Service.....	31
	3.6 Residual risks.....	31
	3.6.1 Electrical dangers.....	32
	3.6.2 Mechanical dangers.....	35
	3.6.3 Noise and ergonomics.....	38
	3.7 Operator's obligations.....	41
	3.8 Who is permitted to use the nutrunner?.....	42
	3.9 Personal protective equipment.....	43
	3.10 Environmental protection.....	45
4	Determining the application	46
5	Preparing the DA2motion	47
6	Supplying with energy	50
	6.1 Battery care.....	50
	6.2 Charging the battery.....	52
	6.3 Connecting the nutrunner to the battery.....	53
7	Setting the torque levels	54
8	Using the DA2motion reaction arm	55
9	Opening and closing fittings with DA2motion	58
10	Using the Diagnostic Setting Software DSS	62
	10.1 Connecting to the DSS.....	63
	10.2 Getting to know the DSS.....	65
	10.3 Customizing.....	66
	10.4 Tool diagnostic.....	68

10.5	Settings.....	70
10.6	Help.....	71
11	Performing maintenance.....	72
11.1	Maintenance schedule.....	72
11.2	Having the nutrunner maintained by the user.....	74
11.3	Having service tasks performed by the manufacturer.....	75
12	Troubleshooting.....	76
12.1	Identifying faults.....	76
12.2	DSS – Error messages.....	77
12.3	Performing troubleshooting.....	78
13	Disposing of the nutrunner.....	80
14	Technical data.....	81
15	Index.....	83
	Appendix.....	86
A	Torque selection diagram for DA2motion	88



1 Unpacking

Delivery



Fig. 1: Transport case

The nutrunner is delivered in a plastic transport case together with the other items in the scope of delivery.

The transport case is packed in a cardboard box upon delivery.

The transport case is fitted with a foam inlay. The recesses in the inlay enable precision storage of the scope of delivery.

Checking the delivery



Check the delivery for transport damage and ensure it is complete immediately upon receipt. If it is incomplete or if there are defects, note the extent of the damage on the transport documents and lodge a complaint immediately.

Scope of delivery for DA2motion



Fig. 2: Transport case for DA2motion

The standard scope of delivery for the DA2motion comprises:

- Transport case
- Trolley
- DA2motion
- Telescopic reaction arm with adapter
- Digital revolution counter

- Circlip pliers
- Circlip
- Document folder
 - Operating instructions
 - Torque selection diagram (not dependent on the serial number)
 - EU declaration of conformity
 - Technical data sheet
- Batteries
- Battery charger

Options:

- Telescopic adapter (e.g. for ground fittings)
- Handwheel adapter

Further accessories are optionally available.

Handling packaging material

The individual packages are packed according to the expected transport conditions. Only environmentally friendly materials are used for the packaging.

The packaging should provide protection against transport damage, corrosion and other damage. For this reason, do not destroy the packaging and do not remove it until shortly before use.

Dispose of packaging material in accordance with the applicable statutory provisions and local regulations.



ENVIRONMENT!

Danger to the environment due to incorrect disposal!

Packaging materials are valuable raw materials and, in many cases, can be further utilised or appropriately reconditioned and recycled. Incorrect disposal of packaging materials can be hazardous to the environment.

- Reuse pallets.
- Dispose of packaging materials in an environmentally sound manner.
- Observe the locally applicable disposal regulations. If necessary, engage the services of a specialist company with regard to disposal.

Transport and storage

Always store and transport the nutrunner in the transport case.

Set the direction of rotation to the middle position (transport position) .

Do not take the nutrunner out of the transport case until shortly before use.

**Transporting batteries**

Batteries contain hazardous substances are classified globally as dangerous goods. These products are therefore only approved for commercial transport under certain conditions.

With regard to road transport in Europe, the regulations of the ADR must be complied with; the regulations of IATA DGR must be complied with for air transport. These contain specifications for packaging and accompanying documentation, for example.



Before transporting hazardous substances, always familiarise yourself with current regulations pertaining to the transport of dangerous goods.

2 Getting to know the nutrunner

2.1 Illustration of the nutrunner

DA2motion




Fig. 3: Illustration of DA2motion

- | | | | |
|---|----------------------------|----|-------------------------------|
| 1 | Revolution counter | 9 | Ventilation slot |
| 2 | Square drive (tool holder) | 10 | Direction of rotation setting |
| 3 | Reaction arm circlip | 11 | Handle |
| 4 | Spacer | 12 | Battery |
| 5 | Safety swivel joint | 13 | Trigger |
| 6 | Gear setting | 14 | Reaction arm lock |
| 7 | Setting levels | 15 | Reaction arm of DA2motion |
| 8 | Drive motor | | |



Illustration of reaction arm of DA2motion





Fig. 4: Illustration of reaction arm of DA2motion

- | | |
|--|-------------------------------------|
| 1 End cap | 4 Reaction arm lock |
| 2 4 lock-in holes on the pull-out lower part of the reaction arm | 5 Revolution counter – RESET button |
| 3 Locking bolt | 6 Revolution counter – Display |

The reaction arm DA2motion can be dismantled into three parts.

The top part with the revolution counter is fastened to the serration of the nutrunner. The middle part is plugged into the top part and locked. The bottom part is plugged into the middle part and locked into one of four points.

Handwheel adapter



- 1 Claw slots with markings
- 2 Square drive holder
- 3 Adjustable claws

With the aid of the handwheel adapter, handwheels can be moved with the nutrunner. The number of claws (2 to 5) can be adjusted to match the handwheel.

Fig. 5: Handwheel adapter

Telescopic adapter – Extension



Fig. 6: Extension

- | | |
|--------------------------------------|---------------|
| 1 Square drive spring clip | 4 Spring clip |
| 2 Locking bolt | 5 Safety bolt |
| 3 Pull-out part with 4 lock-in holes | 6 Adapter |

An extension can be used to operate underfloor fittings more easily, for example.

Battery



- 1 Battery release button
- 2 Electrical contacts and guide rail
- 3 Battery charge status indicator button
- 4 4 LEDs for battery charge status indicator

Fig. 7: Illustration of battery

Battery charger



- 1 LED display
- 2 Battery connection
- 3 Power cable (not shown)

Fig. 8: Illustration of battery charger

2.2 Brief description

The nutrunner DA2*motion* is a hand-held tool for opening and closing fittings in a dry environment.

The nutrunner is powered electrically with the aid of a battery.

A telescopic reaction arm is used to brace the tool against the torque.

The desired torque can be selected by switching the gearbox stages and by actuating the setting potentiometer.

The nutrunner DA2*motion* is **not** suitable for bolting processes.



2.3 Rating plate

Nutrunner

The following data is inscribed on the rating plate:

- Name of the manufacturer including their full address
- Machine designation
- Type designation
- Article/serial number
- Maximum torque
- Year of construction
- Weight
- CE mark

2.4 Performance variables

Overview of the available performance variables for the nutrunner:



DA2 motion

DA2motion 05

DA2motion 10

2.5 Nutrunner controls




Fig. 9: Controls

- | | | | |
|---|--|----|--|
| 1 | Gear setting | 7 | 4 LEDs for battery charge status indicator |
| 2 | Setting levels | 8 | Battery release button |
| 3 | Direction of rotation setting | 9 | Trigger |
| 4 | Handle | 10 | Reaction arm lock |
| 5 | Battery charge status indicator | 11 | Locking bolt |
| 6 | Battery charge status indicator button | 12 | [RESET] revolution counter |

The nutrunner features the following controls:



Gear setting and setting levels




Fig. 10: Gear setting and setting levels

- 1 Gear setting
- 2 Marking for setting level
- 3 Setting levels

The torque is selected using a combination of gear and setting level.

i Note the enclosed torque selection diagram.

Gear: Gear 1 to 4

The gearbox gears are adjusted manually.

The highest torque is obtained in gear 1.

Setting level: Level 1 to 15

The potentiometer is adjusted electronically.

The highest torque is obtained in level 15.

Breakaway torque level:

The breakaway torque level is located at the start and end of the setting level scale .



i The breakaway torque level is not suitable for torque-controlled rotation. Nutrunner, accessories and fitting will be damaged!

Direction of rotation setting



Fig. 11: Direction of rotation setting (1)

The direction of rotation can be changed with the aid of the direction of rotation setting (Fig. 11/1).

i Standard direction of rotation: Right-hand thread


	Direction of rotation setting	Direction of rotation
	Right-hand side is pressed.	Clockwise (CW) Rotation in clockwise direction
	Middle position	No rotation possible. Transport position

	Direction of rotation setting	Direction of rotation
	Left-hand side is pressed.	Counterclockwise (CCW) Rotation in counterclockwise direction

Handle

The nutrunner can be gripped securely and carried by the handle (Fig. 9/4). Ergonomic use of the trigger is possible.

Battery charge status indicator



- 1 Battery charge status indicator
- 2 Button and 4 LEDs for charge status indicator
- 3 Battery release button

A proactive battery charge status indicator is fitted below the handle of the nutrunner. The white LED (Fig. 12/1) warns the user of insufficient battery capacity, thereby preventing a sudden loss of torque.

Fig. 12: Battery charge status indicator




Fig. 13: Charge status

Level	LED	Meaning
0	LED is not illuminated	Battery charged.
1	LED flashing slowly	There is still approx. 30% of the usable battery capacity available. Rotations are still possible with the set torque.
2	LED flashing rapidly	Battery capacity is no longer sufficient to achieve the set torque. The nutrunner switches off automatically. It is no longer possible to continue working.



Button and LEDs for charge status indicator



Fig. 14: LED display and charge status indicator button

 *The battery charge status can only be displayed correctly when the drive motor is switched off.*


The battery charge status is displayed (as a percentage) by pressing the button.

LED	Meaning
1 to 4 LEDs light up green	The charge status is displayed as a percentage: 25% – 50% – 75% – 100%
LED lights up red continuously	The battery is empty. Charge the battery.
LED flashes red	The battery is not operational. Bring the battery to within the operating temperature range and then charge it.

Battery release button

The battery is released from the nutrunner using the release button (Fig. 12/3) and can be removed.

Trigger



A rotation is initiated at the square drive with the trigger (Fig. 9/9) and is executed for as long as the trigger is pressed.

The trigger has a potentiometer function. The more the trigger is pressed, the more power the drive provides. The full torque and speed is achieved when the trigger is fully pressed.

This function makes it easier to move a fitting carefully to the end positions. The end positions **must** be approached slowly. Between these positions, the full power with maximum rotational speed and the highest speed can be used.

 **WARNING!**
Danger of injury due to strong forces in the end positions!

If the end positions of a fitting (fully open/closed) are approached at high speed or high torque, this could destroy the fitting, nutrunner and attachment parts of the nutrunner and cause serious injuries.

- Always approach end positions with care.
- Use the potentiometer function of the DA2motion trigger carefully. Use a low speed.

Reaction arm of DA2motion

The reaction arm of the DA2motion can be removed for transport purposes.

Attach the reaction arm, lock it and set to the desired length prior to use.




Fig. 15: Lock for reaction arm of DA2motion

- 1 Revolution counter
- 2 Back of lock
- 3 Reaction arm
- 4 Lock

Revolution counter of DA2motion



Fig. 16: Revolution counter

- 1 Display
- 2 [RESET]

The revolution counter counts pulses from which the revolutions of the square drive of the nutrunner can be determined.

When opening and closing fittings, this information facilitates a careful approach to the end stops (fitting fully open/closed).



[RESET] can be used to reset the display to "0".

"Counting down" is not possible. The display must be reset to "0" by pressing [RESET] once the desired end position has been reached. In order to return to the starting position after changing the direction of rotation, it is necessary to approach the same display value as before resetting.

LED display for battery charger

LED display	Meaning
	Continuous yellow light The battery charger is operational. Mains voltage is available.



LED display		Meaning
	Flashing green light	Quick charging is active.
	Continuous green light	Quick charging has concluded.
	Flashing red light	Charging is not possible. Potential causes: <ul style="list-style-type: none"> ■ The contacts are dirty. Measure: Clean the contacts by inserting and removing the battery multiple times. ■ The battery is faulty. Measure: Replace the battery.
	Flashing green light and flashing red light	The battery temperature is located outside the charging temperature range of +5 to +45°C. If the battery reaches the permissible charging temperature range, quick charging is initiated.

2.6 Overview of functions

DA2motion

The nutrunner offers the following functions:

- Open and close fittings
- Torque can be set via 4 gears and 15 setting levels
- Trigger with potentiometer function
- Pull-out reaction arm
- Revolution counter
- Diagnostic Setting Software DSS (option)
 - Read out data from the nutrunner.
 - Block individual torque levels.
 - Update the firmware.
 - Save the status report as a PDF file.
- Automatic safety swivel joint
- Automatic release function

Automatic safety swivel joint

The safety swivel joint between the drive motor and gearbox makes it possible to rotate the handle into any position you wish. As soon as the torque on the handle exceeds 2 Nm, the safety swivel joint is automatically locked such that no reaction force is applied to the user's hand.

If the nutrunner is switched off, the safety swivel joint is unlocked again and can be rotated freely.

Automatic release function

Load on the gearbox is relieved after the rotation process. The reaction arm retracts slightly. This makes it easier to remove the nutrunner from the fitting and facilitates further work.

Software – DSS (option)

Diagnostic Setting Software DSS (option)

Information about the nutrunner can be read out from the nutrunner and the nutrunner can be configured.

2.7 Accessories

The following accessories can be ordered in addition to the nutrunner and can be enclosed with the delivery:

- “Torque Control TC1” mobile measuring unit
- Certificate
Technical, more detailed supplement to the torque selection diagram



Accessories for the DA2motion

The following accessory has been specially designed for the DA2motion:

■ Extensions



Fig. 17: Extension accessory for DA2motion

- | | |
|---|--------------------------|
| 1 Square drive holder | 4 Pull-out part |
| 2 4 lock-in holes on the pull-out part of the extension | 5 Adaptation for fitting |
| 3 Locking bolt | |

■ Attachment for pillar hydrants



Fig. 18: Attachment for pillar hydrants

■ Offset head STX 22-02 TL-S slider



Fig. 19: Offset head STX 22-02 TL-S slider

Special accessories

 *Contact PLARAD[®] service.*

3 Before you begin

This section provides an overview of all safety aspects that are essential to the best possible protection of the personnel and the safe and trouble-free operation of the machine. Additional safety instructions for specific work tasks are contained in the sections regarding the individual life stages of the machine.

3.1 Symbols in this manual

Safety instructions

Safety instructions are indicated by symbols in this manual. The safety instructions are initiated by signal words that indicate the degree of the danger.

**DANGER!**

This combination of symbol and signal word indicates an imminently dangerous situation which, if not avoided, will result in death or serious injury.

**WARNING!**

This combination of symbol and signal word indicates a potentially dangerous situation which, if not avoided, could result in death or serious injury.

**CAUTION!**

This combination of symbol and signal word indicates a potentially dangerous situation which, if not avoided, could result in slight or minor injuries.

**NOTICE!**

This combination of symbol and signal word indicates a potentially dangerous situation which, if not avoided, could result in damage to property.

**ENVIRONMENT!**

This combination of symbol and signal word indicates potential dangers to the environment.

Safety instructions in specific instructions

Safety instructions may refer to specific, individual instructions. Such safety instructions are integrated into the instruction so that they do not interrupt the flow of reading when carrying out the task. The signal words described above are used.



Example:

1.  Loosen the screw.

2. 



CAUTION!
Risk of pinching by cover!

Close the cover carefully.

3.  Tighten the screw.

Tips and recommendations



This symbol highlights useful tips and recommendations as well as information designed to ensure efficient and smooth operation.

Other markings

The following markings are used in this manual in order to highlight instructions, outcomes, lists, references and other elements:

Marking	Explanation
	Step by step instructions
	Outcomes of steps
	References to sections of this manual and to other applicable documents
	Lists without a fixed order
[Button]	Controls (e.g. buttons, switches), indicators (e.g. signal lamps)
"Display"	Display elements (e.g. on-screen buttons, assignment of function keys)

3.2 Symbols on the nutrunner

Overview




Fig. 20: Symbols

- | | | |
|---|----------------------------------|--|
| 1 | Nutrunner rating plate | |
| 2 | Test badges | |
| 3 | Battery charger rating plate | |
| 4 | Programming adapter rating plate | |
| 5 | DA2motion revolution counter | |
| 6 | DA2motion reaction arm | |
| 7 | Battery rating plate | |



Illegible signage



WARNING!

Danger in the event of illegible signage!

Over time, signs and stickers can become dirty or be rendered unrecognisable by other means, such that hazards cannot be recognised and necessary operating instructions cannot be followed. This creates a danger of injury.

- Keep all safety notices, warnings and operating instructions in a clearly legible state at all times.
- Replace damaged signs and stickers immediately.

The following symbols and information notices are located on the nutrunner:

Voltage



The equipment marked in this way is supplied with electrical energy.

Do not open the nutrunner.

Danger of crushing



Keep your hands away from areas bearing this warning.

There is a danger of body parts being crushed, pulled in or otherwise injured.

It is necessary to pay greater attention when performing work at the marked locations.

Hot surface



Hot surfaces, such as the housing of the drive motor, cannot always be identified as such. Do not touch surfaces marked in this way without protective gloves.

Follow the manual




Read the operating instructions prior to using the nutrunner.

Wear PPE



Wear the prescribed personal protective equipment to protect against mechanical injuries and noise.

Protection class II



This symbol indicates protection class II. Equipment of protection class II has reinforced insulation between active and touchable parts.

Separate collection



Do not dispose of waste electronic and electrical equipment marked with this symbol in household waste.



Test badges

The test badges state the dates of the respective tests.



Date of the next PLARAD[®] service.



For nutrunners with certificate:

Date of the last torque test.

Reaction arm



Maximum permissible torque for the reaction arm.



3.3 Intended use

The battery nutrunner DA2*motion* is a hand-held tool and may only be used for opening and closing fittings and as a moving machine within the defined specifications (☞ *Chapter 14 "Technical data" on page 81*).

The nutrunner may only be used in a commercial setting and must not be used in a potentially explosive atmosphere.

The nutrunner may only be used in a dry environment.

Intended use includes compliance with all of the stipulations in this manual.



WARNING!

Danger of injury due to unadjusted torque levels!

The torques of the application may vary significantly from the torque values in the torque selection diagram. This could result in injuries and property damage.

- Make your selection with great care.
- Determine the specific application and adjust the torque levels.

3.4 Misuse

Any use beyond the intended use as well as any other use is considered misuse.



WARNING!

Danger in the event of misuse!

Misuse of the nutrunner can lead to dangerous situations.

- Never use the *DA2motion* for bolted connections.
- Never move the nutrunner to the end position at full speed. Reduce speed beforehand.
- Never operate without the reaction arm.
- Do not operate the nutrunner in continuous operation.
- Never subject the nutrunner, fittings and accessories to loads in excess of the permissible torque.
- Never operate unless properly braced.
- Never disregard protection classes.
- Never operate outside the permissible environmental conditions.
- Never process applications that are not accounted for in the torque selection diagram.
- Never operate with batteries other than the original batteries supplied by the manufacturer.
- Do not switch on the nutrunner in a damp environment.
- Never change the gear setting or setting levels during operation.

3.5 General safety instructions for electric tools

EN 62841-1

Safety instructions as per EN 62841-1 VDE 0740-1:2016-07

Electric motor-operated hand-held tools, transportable tools and lawn and garden machinery – Safety Part 1: General requirements

Read all safety information, instructions, illustrations and technical data provided with this electric tool. Failure to comply with the following instructions could cause electric shock, fire and/or serious injuries.

Keep all safety information and instructions for future reference.

The term “electric tool” used in the safety instructions refers to mains-operated electric tools (with mains lead) or to battery-operated electric tools (without mains lead).

3.5.1 Workplace safety

- Keep your work area clean and well lit.
Untidiness and unlit work areas can cause accidents.
- Do not work with the electric tool in potentially explosive environments in which there are flammable liquids, gases or dusts.
Electric tools generate sparks that could ignite the dust or fumes.
- Keep children and other persons away from the electric tool while it is in use.
You could lose control of the electric tool if you are distracted.

3.5.2 Electrical safety

- The plug of the electric tool must fit into the socket. The plug must not be modified in any way. Do not use any adapter plugs together with any electric tools connected to protective earth.
Unmodified plugs and suitable sockets reduce the risk of electric shock.
- Avoid bodily contact with earthed surfaces such as pipes, heaters, stoves and refrigerators.
There is an increased risk of electric shock if your body is earthed.
- Keep electric tools away from rain and moisture.
If water penetrates an electric tool, the risk of electric shock increases.
- Do not misuse the power cable by using it to carry or hang up the electric tool, or to pull the plug out of the socket. Keep the power cable away from heat, oil, sharp edges and moving parts.
Damaged or entangled power cables increase the risk of electric shock.
- If you are working outdoors with an electric tool, only use extension cables that are suitable for use outdoors.
The use of an extension cable suitable for use outdoors reduces the risk of electric shock.
- If operation of the electric tool in a damp environment is unavoidable, use a residual current-operated circuit breaker.
The use of a residual current-operated circuit breaker reduces the risk of electric shock.

3.5.3 Personal safety

- Be attentive, pay attention to what you are doing, and take the utmost care when working with an electric tool. Do not use any electric tools if you are tired or are under the influence of drugs, alcohol or medicines.
A moment of inattention when using the electric tool could result in serious injuries.
- Wear personal protective equipment and always wear safety goggles.
The wearing of personal protective equipment, such as a dust mask, non-slip safety shoes, hard hat or hearing protection, reduces the risk of injury depending on the type and use of the electric tool.
- Avoid unintentional commissioning. Ensure that the electric tool is switched off before you connect it to the power supply and/or the battery, pick it up or carry it.
If you have your finger on the switch when carrying the electric tool or if you connect the electric tool to the power supply when it is switched on, this can result in accidents.
- Remove the adjustment tools or spanner before you switch on the electric tool.
A tool or spanner that is in a rotating part of the electric tool can cause injuries.
- Avoid adopting an unnatural posture. Ensure you have a secure footing and maintain your balance at all times.
This gives you better control of the electric tool in unexpected situations.
- Wear suitable clothing. Do not wear any loose clothing or jewellery. Keep your hair and clothes away from moving parts.
Loose clothing, jewellery and long hair can get caught in moving parts.
- Do not be lulled into a false sense of security and do not disregard the safety rules for electric tools, even if you are familiar with the electric tool from having used it many times.
Careless conduct can cause serious injuries in a split second.

3.5.4 Using and handling the electric tool

- Do not overload the electric tool. Use the designated electric tool for your work.
You can work better and more safely within the specified power range with the right electric tool.
- Do not use any electric tools with a faulty switch.
An electric tool which can no longer be switched on or off is dangerous and must be repaired.
- Unplug the plug from the socket and/or remove a removable battery before you make any device settings, exchange any plug-in tool parts or put away the electric tool.
This precautionary measure prevents the electric tool from starting up unintentionally.

- Store unused electric tools out of reach from children. Do not allow any person to use the electric tool if the person in question is not familiar with the electric tool or if they have not read the instructions.

Electric tools are dangerous if they are used by inexperienced persons.

- Take good care of electric tools and plug-in tools. Check that moving parts are functioning flawlessly and do not jam; check whether parts are broken or damaged in such a way that the function of the electric tool is impaired. Have damaged parts repaired prior to using the electric tool.

Many accidents are caused by poorly maintained electric tools.

- Use electric tools, plug-in tools etc. in accordance with these instructions. In this regard, give due consideration to the working conditions and to the work to be performed.

Use of electric tools for purposes other than the intended uses can lead to dangerous situations.

- Keep handles and gripping surfaces dry, clean and free of oil and grease.

Slippery handles and gripping surfaces mean that safe operation and control of the electric tool is not possible in unforeseen situations.

3.5.5 Service

- Have your electric tool repaired by qualified specialist personnel without exception and using only original spare parts.

This ensures that the safety of the electric tool is maintained.

3.6 Residual risks

The following section outlines the residual risks potentially posed by the nutrunner even when it is used as intended.

To reduce the risks of personal injury and property damage and to avoid dangerous situations, observe the safety instructions listed here and the safety instructions in the other sections of this manual.

3.6.1 Electrical dangers

Electrical current



DANGER!

Danger of death due to electric shock!

If contact is made with live parts, there is an immediate danger of death due to electric shock.

Damage to the insulation or individual components can be life-threatening.

- Do not open the nutrunner.
- If the housing is damaged, disconnect the battery from the nutrunner immediately and arrange for repair.
- Never operate the nutrunner if the trigger is faulty.
- Keep moisture away from live parts. Moisture can cause short circuits.
- Never operate the battery charger with a mains voltage and mains frequency other than those specified on the rating plate.
- Only operate the nutrunner with original batteries supplied by the manufacturer.
- Ensure that the power supply complies with local regulations.
- Never make modifications to the nutrunner, battery or battery charger.
- Never modify the power plug or power cable for the battery charger.
- Only operate the battery charger at suitable power sockets.
- Never operate after the test period has passed. See the test seal regarding the date for the next test.
- Never operate in a potentially explosive atmosphere.
- Keep away from moisture, liquids, steam, dust and coarse contamination.
Do not switch on in a damp environment or in the rain.
- If possible, operate the battery charger with a residual current-operated circuit breaker installed.
- When charging the battery charger with mobile power generators, ensure continuous and constant compliance with the specified values for voltage, frequency, sufficient power and earthing.



Batteries



WARNING!

Danger of death due to fire, explosion, smoke and toxic gases if batteries are handled incorrectly!

Incorrect handling of rechargeable batteries can result in fire, explosions and electric shock. Escaping gases or smoke can lead to poisoning and suffocation.

- Never charge batteries.
- Only use and charge batteries supplied by the manufacturer.
- Only use the charger included in the delivery to charge the battery.
- Only insert a battery with the correct polarity (+/-) in the charger. If the battery cannot be inserted properly, never use force to insert it.
- Never short-circuit the contacts (positive and negative terminal) of the battery.
- Never modify, drill, open, disassemble or subject the battery to mechanical loads.
- Never charge batteries that are clearly damaged. Do not put inflated, dropped or damaged batteries into service. Dispose of them in the proper manner.
- Never expose the battery to moisture or humidity (rain, saltwater, liquids). A humid or moist battery must not be used or charged under any circumstances.
- Avoid permanent damage due to deep discharge of the lithium-ion battery.
- Never use, charge or store the battery in places where there is a potentially explosive atmosphere or where high temperatures could occur.
- Charge lithium-ion batteries in a dry state, at room temperature and in a fireproof location.
- Do not expose to extreme heat. Do not store in the sun or in an overheated car.
- Do not throw the battery into a fire.
- Only use approved chargers.
- Only operate in the designated nutrunners.
- Do not inhale escaping gases or smoke.
- Dispose of in an environmentally sound manner.
- Transport lithium-ion batteries in accordance with the currently applicable legal regulations pertaining to dangerous goods.

EMC



WARNING!

Danger of injury due to very strong electromagnetic radiation!

Very strong electromagnetic radiation can cause the nutrunner to malfunction, resulting in serious injuries and major property damage.

- Do not operate in the immediate vicinity of strong transmitting antennas.
- Suspend use immediately and remove the battery as soon as there are signs of malfunctions.

Batteries



WARNING!

Danger of injury if batteries are handled incorrectly!

The revolution counter contains a lithium button cell.

If batteries are handled incorrectly, there is the danger that batteries will explode or that harmful substances will escape from the batteries. Skin contact could cause burns, ingestion could cause severe poisoning, and eye contact could cause blindness.

- Do not open the revolution counter. Do not replace the battery yourself. (Service life of the battery: approx. 8 years)
- Never attempt to charge batteries.
- Always protect batteries against access from unauthorised persons, especially children.
- Dispose of the revolution counter as an old electronic device without disassembly.



3.6.2 Mechanical dangers

Moving components and rotational movements



WARNING!

Danger of injury due to moving components!

Moving components can cause serious injuries. There is a danger of being pulled in during rotational movements.

Dirt can be ejected from the lower ventilation slots and cause eye injuries.

- During operation, do not reach into moving components or handle moving components. Grip the reaction arm securely at the outermost end if it cannot be braced against an on-site structural element. Only press the trigger slowly. Do not touch the drive shaft, extension or other moving attachment parts. Do not reach into the handwheel adapter.
- Secure the extension (accessory for DA2motion), reaction arm and impact socket wrench properly with the circlips prior to commissioning ↪ Chapter 5 “Preparing the DA2motion” on page 47.
- Never move to the end position at full speed. Always reduce the speed beforehand.
- Do not switch on the nutrunner while carrying it. Set the direction of rotation to the middle position. Transport the nutrunner in the transport case.
- Never open the nutrunner.
- Wear tight fitting work clothing that resists tearing to some degree.
- Wear safety goggles.
- Protect long hair from being pulled in by rotating parts using a protective cap (hair net).

Incorrect bracing and overloading



WARNING!

Danger of injury due to incorrect bracing, overloading, breakage!

Incorrect bracing or overloading of the nutrunner or individual components can result in serious injuries.

- Do not use the nutrunner if you are uncertain about any of the job parameters.
- Note the torque selection diagram.
- Check the reaction arm for visible damage prior to use. Do not use the reaction arm if it is damaged.
- Brace the reaction arm correctly ↗ “Bracing” on page 57.
- Do not use the nutrunner in continuous operation.
- Use only PLARAD[®] original parts.

Reaction arm



The reaction arms are designed for a maximum permissible load.

Observe the stickers on the reaction arm and data sheet.

Crushing



WARNING!

Danger of crushing when bracing and due to high weight!

During operation, very strong forces act on the nutrunner, reaction arm, bracing surface and fittings. There is a danger of crushing between the reaction arm and bracing surface. The high weight of the nutrunner can cause crushing if it falls down.

- Handle the nutrunner with care and as intended.
- Give due consideration to the weight during transport and during all work.
- Have work performed only by persons who are physically capable of using the nutrunner safely despite its high weight.
- Do not reach between the reaction arm and bracing surface.
- Secure the nutrunner against falling when working at height.
- Wear safety shoes.
- Also wear an industrial safety helmet for overhead work.



End positions of fittings



WARNING!

Danger of injury and property damage due to strong forces in the end positions!

If the end positions of a fitting (fully open/closed) are approached at high speed or high torque, this could destroy the fitting, nutrunner and attachment parts of the nutrunner and cause serious injuries.

- Always approach end positions with care.
- Use the potentiometer function of the DA2motion trigger carefully. Use a low speed.

Dirt and scattered objects



CAUTION!

Danger of injury from falling over dirt and scattered objects!

People may slip on or stumble over dirt and scattered objects. Falling may cause injuries.

- Always keep the work area clean.
- If objects are no longer needed, remove them from the work area and especially if such objects are at ground level.
- Mark unavoidable stumbling points with hazard tape.
- Keep handles and gripping surfaces of the nutrunner dry, clean and free of lubricants. Clean them immediately if they are dirty.

Gear setting and setting levels



NOTICE!

Property damage due to gear and setting level adjustment!

Changing the setting during operation causes property damage including destruction of the nutrunner. Changing the gear causes mechanical damage to the gearbox. Changing the setting levels results in undefined behaviour.

- Only make changes to the gear or setting level settings when the nutrunner is at a standstill.

Conserving materials



In order to prevent premature damage to tools and accessories, only use the nutrunner up to 80% of the maximum torque of the nutrunner during continuous use, if possible to do so.

Especially during loosening, loads could occur that have adversely effect durability.

Torques in excess of 80% (based on the maximum torque of the nutrunner) should only be used in exceptional cases.

3.6.3 Noise and ergonomics

Noise



WARNING!

Danger of injury due to noise!

The noise level of 72 dB(A) (3 dB(A) measurement uncertainty) occurring in the work area can cause hearing damage.

- Make hearing protection available.
- Recommendation: Wear hearing protection.

Hot surfaces



WARNING!

Danger of injury due to hot surfaces!

The surfaces of components, such as the drive motor or gearbox, could heat up significantly during operation. Surface temperatures of up to 80°C could develop. Contact between the skin and hot surfaces will result in severe burns to the skin.

- Always wear protective work clothing and safety gloves when working in the vicinity of hot surfaces.

**Inadequate ergonomics****CAUTION!****Damage to the musculoskeletal system due to the high weight of the nutrunner!**

Lifting and carrying heavy loads can cause permanent damage to the musculoskeletal system.

- Ensure stable footing and sufficient room for movement.
- Keep your back as straight as possible. Do not lift with your upper body hunched over, bent forward, or with your back arched.
- Lift the nutrunner as close to your body as possible.
- Avoid one-sided loading. Avoid twisting your spine. Do not carry one-handed.
- Never move the nutrunner abruptly.
- Use the safety swivel joint to rotate the trigger in such a way that it is possible to work without any discomfort.
- Use suitable auxiliary devices (e.g. lifting eyes).

Inattention**WARNING!****Danger of injury due to distraction, inattention or irresponsible use!**

Distraction, inattention or irresponsible use can result in losing control of the nutrunner and thus cause serious injuries.

- Always keep the work area well-lit.
- Keep children and unauthorised persons away.
- Work purposefully and in a responsible manner. Do not allow yourself to be distracted.
- Do not work if you are tired or under the influence of drugs, alcohol or medicine.
- Do not be lulled into a false sense of security. Do not disregard the safety information and instructions in this manual, even if the nutrunner seems familiar to you after frequent use.
- When the nutrunner is not in use, always store it in the transport case out of reach from children and other unauthorised persons.
- Wear the prescribed personal protective equipment.

Faulty safety devices



WARNING!

Danger of death due to inoperative safety devices!

If safety devices or safety functions are inoperative or disabled, there is a danger of serious injuries.

- Prior to commencing work, check that all safety devices are operative and correctly installed.
- Never disable or bypass safety devices or safety functions.

The nutrunner is equipped with the following safety devices and safety functions:

- Automatic safety swivel joint
The safety swivel joint prevents reaction forces acting on the wrist.
- Automatic release function
Load on the gearbox is relieved after the rotation process. The nutrunner can be removed more easily.
- Insulation of the power cable for the charger
- Protection class 2
- Insulated handle
- Overheating protection for drive motor
The drive motor switches off at the maximum temperature
- Undervoltage detection
The nutrunner switches off if there is undervoltage (loss of power).
- Automatic start-up protection
The nutrunner is protected against automatic start-up when the power supply is switched on.
- Start-up protection/transport position
The nutrunner is protected against unintentional start-up in the middle position of the direction of rotation setting.
- Reaction arm circlip
The reaction arm is protected against outward ejection by means of a circlip.
- Spring clip for tools
Tools are secured against outward ejection by means of a spring clip on the square drive of the nutrunner.
- Acoustic signal

3.7 Operator's obligations

The nutrunner is used in the commercial sector. The operator of the nutrunner is therefore subject to the statutory obligations pertaining to occupational safety.

In addition to the safety instructions in this manual, the applicable safety, occupational safety and environmental protection regulations for the nutrunner's area of application must be adhered to.

The following specifically applies in this regard:

- The operator must familiarise themselves with the applicable occupational safety regulations and, as part of a risk assessment, determine additional dangers that arise as a result of the specific operating conditions at the operating site of the nutrunner. This risk assessment must be implemented in the form of safety instructions for operation of the nutrunner.
- During the entire time the nutrunner is in use, the operator must check whether the safety instructions they have compiled reflect current regulations and, if necessary, the operator must change the instructions accordingly.
- The operator must clearly define and regulate responsibilities for all work on and with the nutrunner. The authority and responsibilities of personnel regarding operation, set-up, maintenance and repair must be clearly defined.
- The operator must reliably check the use of the nutrunner and ensure that only commissioned and instructed personnel work with the nutrunner. Only allow personnel to be trained or instructed and those undertaking vocational training to work on the nutrunner under the supervision of an experienced person.
- The operator must ensure that the nutrunner is not opened and that no work is performed on the electrical equipment by unauthorised persons.

Work on electrical equipment may only be performed by an electrician or by trained persons under the guidance and supervision of an electrician. Adhere to electrotechnical regulations for safety reasons.

The operator is also responsible for ensuring that the nutrunner is in technically flawless condition at all times. The following applies for this reason:

- The operator must ensure adherence to the maintenance intervals described in this manual.
- The operator must have the functionality and integrity of all safety devices checked on a regular basis.

3.8 Who is permitted to use the nutrunner?


WARNING!
Danger of injury if personnel are insufficiently qualified!

If unqualified personnel perform work on or with the nutrunner or if such persons loiter in the danger zone while work is being performed, dangers arise that could cause serious injuries and considerable property damage.

- Have all tasks performed by suitable qualified personnel without exception.
- Keep unqualified personnel away from the danger zones and working areas.

User

The user of the nutrunner has the requisite knowledge and the requisite training for handling electrical tools. Furthermore, as part of training provided by the operator, the user was trained in relation to the tasks assigned to them and the potential dangers associated with improper conduct.

The user is trained in how to use the personal protective equipment, is familiar with the most important specifications, situations and information relating to the specific application and is physically capable of using the nutrunner safely despite its weight. This includes overhead work, working at heights, etc.

The user must be older than the legally permissible minimum age.

Tasks that go beyond operation during normal operation may only be carried out by the user if this is specified in this manual and the operator has expressly entrusted them with the performance of such tasks.

The user knows who their supervisor is, can contact their supervisor if they have questions or in an emergency, and is able to communicate with their supervisor.

The user is familiar with all residual risks and is trained in the practical handling of the nutrunner.

Qualified nutrunner personnel

Qualified nutrunner personnel are trained for the specific task area in which they work and are familiar with the relevant standards and regulations.

Due to their professional training and experience, qualified nutrunner personnel are able to perform work with the nutrunner, recognise and avoid potential dangers independently and convey this to users.

Specific capabilities of qualified nutrunner personnel include:

- Identify the applications.
- Prepare the nutrunner. Select the appropriate adapter.
- Use all functions of the nutrunner.
- Create passwords for users.



- Uphold safety, occupational safety and health protection when using the nutrunner and convey this to users.
- Identify damage on the nutrunner and arrange for repairs or get in touch with the manufacturer.
- Instruct users in the proper manner.

Operator

The operator is the person who operates the nutrunner for commercial or economic purposes themselves, or makes it available for a third party to use, and who bears legal responsibility for the product vis-à-vis protection of personnel and third parties during operation.

🔗 *Chapter 3.7 “Operator’s obligations” on page 41*

PLARAD[®] service

Certain work may only be performed by PLARAD[®] service or by personnel authorised by Maschinenfabrik Wagner GmbH & Co. KG. Other personnel are not authorised to perform this work. Contact PLARAD[®] service or authorised PLARAD[®] partners regarding performance of the work that is due.

Contact: www.plarad.de

🔗 *Chapter 11.3 “Having service tasks performed by the manufacturer” on page 75*

Unauthorised persons



WARNING!

Danger of death for unauthorised persons due to dangers in the danger zone and work area!

Unauthorised persons, who do not meet the requirements described in this manual, are not aware of the dangers in the danger zone. There is therefore a danger of serious injuries or even death for unauthorised persons.

- Keep unauthorised persons away from the danger zone and work area.
- If in doubt, address the respective persons and instruct them to leave the danger zone and work area.
- Suspend work while there are unauthorised persons loitering in the work and danger zone.

3.9 Personal protective equipment

Safety gloves



Safety gloves are used to protect the hands from friction, abrasions, punctures or deeper injuries and from contact with hot surfaces.

Safety shoes



Safety shoes protect the feet from crushing, falling parts and from slipping on slippery ground.

Hearing protection



Hearing protection is used to protect against hearing damage cause by noise.

Safety goggles



Safety goggles are used to protect the eyes from airborne parts and liquid jets.

Protective work clothing



Protective work clothing is tight fitting work clothing that resists tearing to some degree, with tight sleeves and without any protruding parts.

Protective cap



The protective cap (hairnet) is used to protect the hair from being pulled in by rotating and moving parts, such as bolts.

The wearing of a protective cap is mandatory if your hair is longer than the circumference of the moving shaft.

Industrial safety helmet



Industrial safety helmets are used to protect the head from falling objects, suspended and swinging objects and from bumping into stationary objects.

An industrial safety helmet must be worn for overhead work involving the nutrunner.



3.10 Environmental protection



ENVIRONMENT!

Danger for the environment due to incorrect handling of environmentally hazardous substances!

If environmentally hazardous substances are handled incorrectly, especially if such substances are disposed of incorrectly, this could cause significant damage to the environment.

- Always adhere to the instructions given below in relation to the handling of environmentally hazardous substances and the disposal thereof.
- If environmentally hazardous substances accidentally enter the environment, adopt suitable measures immediately. If in doubt, notify the competent local authority of the damage and inquire about suitable measures to be taken.

The following environmentally hazardous substances are used:

Batteries and rechargeable batteries

Batteries and rechargeable batteries contain toxic heavy metals. They are subject to special waste treatment and must be deposited at municipal collection points or be disposed of by a specialist company.

Lubricants

Lubricants, such as greases and oils, contain toxic substances. Such substances must not enter the environment.

The nutrunner must not be lubricated by the operator. If lubricants do however escape, arrange for them to be disposed of by a specialist disposal company.

Electrical and electronic components

Electrical and electronic components contain toxic materials. These components must be collected separately and deposited at municipal collection points or be disposed of by a specialist company.

4 Determining the application

The torque setting of the nutrunner must be made for each application individually and checked directly during the application.

Use a rotating, electrical measuring transducer or a calibrated torque spanner for checking purposes.

Personnel: ■ Operator

The nutrunner can only be used safely and properly if the application is known.



Fig. 21: Mobile measuring unit TC1

1. Determine the application. To do so:

Determine a suitable bracing surface and set up bracing accordingly.

2. Determine the requisite torques for the application.

To this end, measure the applied torque when undoing and closing a fitting, e.g. using the mobile measuring unit TC1 (not included in the scope of delivery; see available accessories).

3. Make further accessories (bracing aids, suspension etc.) available according to the situation.



5 Preparing the DA2motion

Unsecured or overloaded components




WARNING!

Danger of injury due to unsecured or overloaded components!

Unsecured components or components subjected to loads exceeding the intended use could result in uncontrolled nutrunner behaviour, outward ejection of components or breakage and thereby cause serious injuries.

- Carefully determine all parameters for an application.
- Ensure that all components are used within the scope of their intended use.
Never exceed load limits (e.g. maximum torques).
- Never put the nutrunner into operation if the reaction arm is unsecured.

- Personnel: ■ Qualified nutrunner personnel
- Protective equipment: ■ Protective work clothing
 ■ Safety shoes



Prior to use, the application must be known and the nutrunner must be prepared.

- 1.** → Ensure that the application has been determined and that all parameters are available.
- 2.** → Carefully slide the spacer (Fig. 22/4) over the serration (Fig. 22/5) and onto the nutrunner.
- 3.** → Secure the spacer with two screws (Fig. 22/3).
- 4.** → Attach the top part of the reaction arm with revolution counter (Fig. 22/2) to the serration (Fig. 22/5).

Fig. 22: Securing the reaction arm

- 1 Circlip
- 2 Top part of the reaction arm with revolution counter
- 3 Safety bolt
- 4 Spacer
- 5 Serration



Fig. 23: Circlip pliers

5. ➔ Slide on the circlip (Fig. 22/1) with the aid of the circlip pliers (Fig. 23) and clamp it.
⇒ The reaction arm is secured.




Fig. 24: Securing the accessory

- 1 Accessories
- 2 Bores
- 3 Square drive with bore
- 4 Spring clip

6. ➔ Attach the accessory to the square drive on the nutrunner and secure it.
To do so, push the accessory (Fig. 24/1) fully onto the square drive (Fig. 24/3). The bores (Fig. 24/2 and 3) for securing must be on top of each other.
Fully insert the spring clip (Fig. 24/4) in all bores (Fig. 24/2 and 3) until the ring is fully seated.
⇒ The accessory is now secured.
7. ➔ Attach further accessories if such accessories are necessary for the application.




Fig. 25: Reaction arm

- 1 Lock
- 2 Middle part of the reaction arm

8. ➔ Turn the lever of the lock (Fig. 25/1).
9. ➔ Fully attach the middle part of the reaction arm (Fig. 25/2) and lock it.
⇒ The bolt (Fig. 26/1) is engaged correctly in the lock (Fig. 26/2).




Fig. 26: Correct lock

- 1 Bolt
- 2 Lock

10.▶



WARNING!
Danger of injury due to reaction arm coming loose!

Ensure that the lock is fully engaged.




Fig. 27: Extending the reaction arm

- 11.▶ Plug the bottom part of the reaction arm into the middle part. To do so, pull the locking bolt (Fig. 27/2), push the bottom part into the middle part as far as you wish, and let the locking bolt (Fig. 27/2) lock into place in one of the four lock-in holes (Fig. 27/1).

12.▶



WARNING!
Danger of injury due to reaction arm coming loose!

Ensure that the reaction arm is fully engaged.

6 Supplying with energy

6.1 Battery care

Battery care instructions

In order to obtain the full performance, lithium-ion batteries (Li-Ion) require care.

Battery care rules

- The first charging process is crucial. Charge the battery fully prior to first use.
- Each battery has a limited number of charge cycles. For this reason, do not recharge the battery at every opportunity. Instead, wait until a charge status of between 10% and 20% capacity before recharging.
- If the battery is discharged below its nominal voltage, the battery could be damaged or destroyed. The batteries included in the delivery therefore have electronics that warn of deep discharge and switch off the nutrunner.
- Frequent overcharging can cause permanent damage to the battery. The charger automatically concludes the charging process if the battery is fully charged. Do not connect the battery again.
- The battery can only be charged at temperatures between 5°C and 45°C. To avoid damaging the battery cells, do not charge the battery when it is cold. Let it warm up to room temperature beforehand. Charge the battery at room temperature (18°C to 21°C).
- High temperatures damage the battery. Never leave the battery or the transport case in the car or in the sunshine on hot days. The lithium-ion battery loses capacity and performance capability at temperatures above +60°C.
- Do not store lithium-ion batteries empty or fully charged for a prolonged period of time. Optimum storage at a capacity of 40% to 50% and at temperatures of 5°C to 10°C.
- Store unused batteries in a cool but not cold location. Batteries also lose energy in an unused state. The energy loss for lithium-ion batteries is approx. 3% to 5% per month.
- If a lithium-ion battery is not used for a prolonged period of time, recharge the battery after 12 months at the latest.
- Always dispose of old and used batteries in an environmentally sound manner.

Storing the battery

Optimum storage temperature: 5°C to 10°C.

Lithium-ion batteries (Li-Ion) should not be stored empty or fully charged for a prolonged period of time. Optimum storage, which was determined in an extensive series of tests, is at 40% to 50% of capacity and at low temperatures, but not below 0°C. Due to self-discharge, recharging is required every 12 months at the latest.

Battery not in use for a prolonged period of time

Disconnect the battery from the nutrunner if the nutrunner will not be used for a prolonged period of time.



Even when the device is switched off, a small current can flow that leads to a deep discharge after a prolonged period of time. Deep discharge damages the battery and, in extreme cases, will destroy it.

Self-discharge

A charge loss of 3% to 5% per month is possible for lithium-ion batteries. The self-discharge is temperature-dependent and greater at high temperatures.

Deep discharge

The capacity of the battery is fully exhausted in the event of deep discharge. In such cases, the voltage drops to as low as 0 volt.

In the battery, chemical reactions take place on the electrodes. Such reactions can render them unusable. The battery loses considerable capacity and can potentially no longer be charged. For this reason, the battery must not be discharged below a type-dependent end-of-discharge voltage and must be recharged as quickly as possible.

 *Do not fully discharge lithium-ion batteries and lithium-ion polymer batteries.*

Good lithium-ion batteries usually have extensive protection or monitoring circuits in the battery pack that prevent deep discharging/overcharging and explosion.

Temperature range for battery operation

Temperature range for use: -10°C to +55°C

Temperature range for charging: +5°C to +45°C

The ideal temperature range for batteries is at room temperature. A sensor in the battery ensures that no quick charging takes place outside this range.

Service life of batteries

Lithium-ion batteries can be charged up to 1,000 times (capacity-dependent). This value is only achieved under optimum conditions.

The number of cycles could decrease depending on battery treatment and care. The capacity decreases over the course of the service life.

Batteries should generally be replaced below 70% nominal capacity.

Memory effect, lazy battery effect

Lithium-ion batteries and lithium-ion polymer batteries can and may be recharged at any time. These batteries do not have any memory effect. It is only necessary to avoid frequent brief charging. Even full charging in several stages, with or without partial discharge in between stages, does no harm.

Lithium-ion batteries and lithium-ion polymer batteries must not be fully discharged.

6.2 Charging the battery

The first time



Charge the battery fully prior to first-time use.

Electrical current



DANGER!

Danger of death due to electric shock!

If contact is made with live parts, there is an immediate danger of death due to electric shock. Damage to the insulation or individual components can be life-threatening.

- If the housing is damaged, disconnect it from the power supply immediately and arrange for repair.
- Keep moisture away from live parts. Moisture can cause short circuits.
- Never operate with a mains voltage and mains frequency other than those specified on the rating plate.
- Ensure that the power supply complies with local regulations.
- Never modify the power plug or power cable.
- Only operate at suitable power sockets.
- Never operate after the test period has passed. See the test seal regarding the date for the next test.
- Keep away from moisture, liquids, steam, dust and coarse contamination.
Do not switch on outdoors, in a damp environment or in the rain.
- During operation with mobile power generators, ensure continuous and constant compliance with the specified values for voltage, frequency, sufficient power and earthing.



Battery charger



The batteries (Fig. 28/2) can be charged using the battery charger (Fig. 28/1) included in the scope of delivery.


Fig. 28: Charging the battery

Setting up the charger



1. ➔ Set up the battery charger in a cool, dry place and connect it to a power socket.
⇒ If the yellow continuous light is illuminated, mains voltage is present and the battery charger is operational.

Inserting the battery



2. ➔ Carefully slide the battery into the battery charger until the locking mechanism clicks into place.
⇒ The charging process begins.

If the green continuous light is illuminated, the battery is fully charged.

Using the battery



4. ➔ Press the release button on the battery (Fig. 29/1) and remove the battery from the battery charger.

Fig. 29: Unlocking the battery

6.3 Connecting the nutrunner to the battery

A charged battery needs to be inserted prior to using the nutrunner.

Charge status

1. ➔ Ensure that the battery is charged. Press the battery charge indicator button in order to check the charge status.

Inserting the battery

2. ➔ Carefully slide the battery into the nutrunner until the locking mechanism clicks into place.
⇒ The nutrunner is operational.

Replacing the battery

3. ➔ In order to remove the battery, press the battery release button and remove the battery.

Insert a charged battery.

7 Setting the torque levels

Gear setting and setting levels



NOTICE!

Property damage due to gear and setting level adjustment!

Changing the setting during operation causes property damage including destruction of the nutrunner. Changing the gear causes mechanical damage to the gearbox. Changing the setting levels results in undefined behaviour.

- Only make changes to the gear or setting level settings when the nutrunner is at a standstill.




Fig. 30: Gear setting and setting levels

- 1 Gear setting
- 2 Marking for setting level
- 3 Setting levels

For each application, the correct torque level must be determined and the gear and setting level must be set accordingly on the nutrunner.

1. Determine the parameters for the application.
2. Find a suitable combination of gear and setting level using the torque selection diagram provided.
3. Set gear (Fig. 30/1) 4 to 1 (manual gearbox setting).
4. Set setting level (Fig. 30/3) 1 to 15 (electronic setting).
 - ⇒ The desired torque level is now set.



The breakaway torque level  at the start and end of the setting level scale, is blocked for both directions of rotation in delivery state. The torque of the breakaway torque level is roughly 15% greater than the torque of setting level 15.

The breakaway torque level can be enabled in the Diagnostic Setting Software DSS.



8 Using the DA2motion reaction arm

Hand-held reaction arm



WARNING!

Danger of crushing from hand-held reaction arm!

The use of the reaction arm without a suitable bracing surface can result in severe crushing.

- Always keep the distance between the rotation axis (square drive) and bracing point (of the reaction arm) as wide as possible. A narrow distance between the rotation axis and bracing position can result in increased forces in the system that cannot be supported by one person.
- Never use your body or body parts to brace the reaction arm.
- Always approach the end positions of the fittings slowly.

Incorrect bracing and overloading



WARNING!

Danger of injury due to incorrect bracing, overloading, breakage!

If the nutrunner is not sufficiently braced, it can slip out of place and be ejected. Any point contact between the reaction arm and the corners of a bracing element can cause considerable forces to act on the nutrunner. Incorrect bracing or overloading of the reaction arm, bracing point or other components can result in serious injuries and damage to the nutrunner.

- Do not use the nutrunner if you are uncertain about any of the job parameters.
- Note the torque selection diagram.
- Check the reaction arm for visible damage prior to use. Do not use the reaction arm if it is damaged.
- Brace the reaction arm correctly. Note the following instructions regarding bracing.
- Always ensure that the reaction arm is in full contact with the surface.
- Use only PLARAD[®] original reaction arms.



WARNING!

Danger of crushing from slewing telescopic bar!

Strong forces arise as a result of using a pulled-out reaction arm. Such forces can cause serious injuries and major property damage.

- Only use suitable bracing points of sufficient size and strength.
- Never use people to brace the tool.
- Note the direction of rotation.
- Change the stop side when changing the direction of rotation.
- Ensure that the slewing range of the reaction arm or telescopic bar is clear of people.

Reaction arm



The reaction arms are designed for a maximum permissible load.

Observe the stickers on the reaction arm and data sheet.

Bracing the DA2motion reaction arm




Fig. 31: Reaction arm

At low torques only: when operating fittings, you can brace the reaction arm by hand.

1. ➤ Ensure that the reaction arm is properly secured ↗ *Chapter 5 "Preparing the DA2motion" on page 47.*
2. ➤ Pull out the reaction arm according to requirements. Ensure that the bottom part of the reaction arm is fully engaged.
3. ➤ Ensure that no crushing points are formed with objects in the vicinity.
4. ➤ Ensure stable footing.
5. ➤ Always use the nutrunner with care. Always increase the torque slowly.
6. ➤ At higher torques, or if there is a risk of crushing injury when bracing by hand, find a suitable bracing point on an on-site structural element ↗ *"Bracing" on page 57.*



Bracing



1. → Find an ideal bracing point suitable for the job at hand on an on-site structural element. Ensure that the reaction arm is in full contact with the bracing surface and cannot slip out of place. Note the starting angle of rotation.

If the standard reaction arm is not suitable for this, use a suitable reaction arm. If you have questions, contact PLARAD[®] service.
2. → Ensure that the nutrunner is braced with the telescopic bar attached and that the bar is in full contact with the surface. Also ensure that the points marked with → () never absorb the torque.

Fig. 32: Reaction arm braced incorrectly

→ Incorrect bracing point

9 Opening and closing fittings with DA2motion

Danger of crushing

**WARNING!****Danger of crushing between the reaction arm and bracing surface!**

Body parts could get between the reaction arm and bracing surface. This could result in serious injuries.

- Never brace the reaction arm by hand at high torques.
- Never put body parts between the reaction arm and any on-site structural elements used for bracing.
- Carefully attach the impact wrench socket or claw adapter.

Overloading and breakage

**WARNING!****Danger of injury due to overloading and breakage!**

Overloading of the nutrunner or individual components can result in serious injuries.

- Do not use the nutrunner if you are uncertain about any of the job parameters.
- Note the torque selection diagram.
- Check the reaction arm for visible damage prior to use. Do not use the reaction arm if it is damaged.
- Brace the reaction arm correctly ↪ *Chapter 8 “Using the DA2motion reaction arm” on page 55.*

End positions of fittings

**WARNING!****Danger of injury and property damage due to strong forces in the end positions!**

If the end positions of a fitting (fully open/closed) are approached at high speed or high torque, this could destroy the fitting, nutrunner and attachment parts of the nutrunner and cause serious injuries.

- Always approach end positions with care.
- Use the potentiometer function of the DA2motion trigger carefully. Use a low speed.



Starting the process



Contact PLARAD[®] service prior to operation at temperatures below 0°C.

1. ➔ Ensure that the nutrunner has been properly prepared (↪ Chapter 5 “Preparing the DA2motion” on page 47) and that the application is known.
2. ➔ Ensure that the battery is charged and correctly connected to the nutrunner ↪ Chapter 6 “Supplying with energy” on page 50.
3. ➔ Ensure that the torque level setting has been made ↪ “Gear setting and setting levels” on page 15.
4. ➔ Attach the nutrunner to the fitting in such a way that the nutrunner cannot slip out of place.
5. ➔ Brace the reaction arm correctly ↪ Chapter 8 “Using the DA2motion reaction arm” on page 55.

Direction of rotation




Fig. 33: Direction of rotation

- 1 Rotation in clockwise direction
- 2 Rotation in counterclockwise direction
- 3 Trigger

6. ➔



Standard direction of rotation: Right-hand thread

	Direction of rotation setting	Direction of rotation
	Right-hand side is pressed.	Clockwise (CW) Rotation in clockwise direction
	Middle position	No rotation possible. Transport position
	Left-hand side is pressed.	Counterclockwise (CCW) Rotation in counterclockwise direction

To rotate in clockwise direction (CW), push the direction of rotation lever (Fig. 33/1) to the right.

To rotate in counterclockwise direction (CCW), push the direction of rotation lever (Fig. 33/2) to the left.

⇒ An acoustic signal sounds if torque levels are blocked.

Revolution counter



Fig. 34: Revolution counter

Trigger

7. ▶ The revolution counter counts pulses. 10 pulses are counted during each revolution of the square drive. The display indicates “10” after one revolution.

To count the revolutions of the square drive, press [RESET] (Fig. 34/2).

⇒ The display (Fig. 34/1) is set to “0”.

The display increases by “10” with every revolution of the square drive (independently of the direction of rotation). Example ↪ “Using the revolution counter” on page 60.

8. ▶



WARNING!

Danger of injury and property damage from rapidly approaching the end positions with high torque!

Press the trigger (Fig. 33/3) carefully.

⇒ The nutrunner starts up slowly due to the potentiometer function of the trigger.

9. ▶ If necessary, push the trigger through outside of the end position areas in order to reach full rotational speed.

10. ▶



WARNING!

Danger of injury from hand-held reaction arm!

Reduce the pressure on the trigger in advance of the end position and approach the end position with care.

⇒ The reaction forces can be felt on the hand-held reaction arm.

Using the revolution counter

The fitting is in an end position (fully closed).

1. ▶ Press [RESET] (Fig. 34/2).

⇒ The display (Fig. 34/1) is set to “0”.

2. ▶ Press the trigger and carefully move the fitting to the other end position (fully open).

3. ▶ Read and take note of the display (Fig. 34/1).

The revolution number is the display value divided by 10.

⇒ It is now known how many revolutions are needed in order to move from one end position to the other.



4. ➔ To reset the display (Fig. 34/1) to "0", press [RESET] (Fig. 34/2).
 - ⇒ As the required revolution number or the display value are known, the full speed can be used for longer and more safely the next time the fitting is closed. The pressure on the trigger does not need to be reduced until shortly before the end position. This indicated by the display value. Collisions can be avoided.

10 Using the Diagnostic Setting Software DSS

Functions

The “Diagnostic Setting Software” (DSS) can be used as an option.
 Functions:

- Read out data from the nutrunner.
- Block individual torque levels.
- Update the firmware.
- Save the status report as a PDF file.

Different functional scope



The functional scope is dependent on the nutrunner.

- Nutrunner without direction of rotation recognition
 Step blocking effects all gears in CW and CCW.
- Nutrunner with direction of rotation recognition
 Step blocking effects all gears. Step blocking in CW and CCW may vary.
- Nutrunner with direction of rotation and gear recognition
 Step blocking can be specified individually for each gear and each direction of rotation.

The different levels are displayed under “*Information*” in the “*Customizing*” menu (↪ *Chapter 10.3 “Customizing” on page 66*).

Scope of delivery



Fig. 35: Programming adapter

The scope of delivery for the Diagnostic Setting Software DSS includes:

- Programming adapter
- USB connection cable
- USB stick with Diagnostic Setting Software DSS and FTDI drivers

System requirements

In order to use the Diagnostic Setting Software DSS, the following system requirements must be met:

- Terminal device with Windows[®] operating system.
 Windows[®] XP, Windows[®] 7, Windows[®] 8, Windows[®] 10
- Installed FTDI[®] VCP driver (Virtual COM port)
 ↪ www.ftdichip.com/Drivers/VCP.htm
- Installed Microsoft .NET Framework 4 Version (or newer)
 ↪ Microsoft Download Center
- USB interface (USB 2.0 or newer)
- Administrator rights (for installation only)



10.1 Connecting to the DSS

Installing the DSS

The “*Diagnostic Setting Software*” programme must be installed on a Windows[®]-compatible terminal device.

1. → Ensure that the system requirements are met ⇨ “*System requirements*” on page 62.

2. → Start the “*Diagnostic Setting Software Installer.exe*” programme.

3. → Select the optional components to install and confirm with .

- Diagnostic Setting Software
- Desktop Shortcut
- Start Menu Shortcuts
- FTDI Driver for USB connection




Fig. 36: DSS installation

4. → Select destination folder for installation.

5. → Press .




Fig. 37: DSS installation

6. → Wait until installation has concluded. Press .

⇨ The programme and the additionally selected components are installed. The programme is ready for operation thereafter.




Fig. 38: DSS installation

Connecting the programming adapter

The FTDI® VCP driver must be installed in order to connect the USB programming adapter ↪ *“Installing the DSS” on page 63.*

1. ➤ Connect the programming adapter to the terminal device using a USB cable.
 - ⇒ An LED on the charge status indicator lights up green.
2. ➤ Start *“Diagnostic Setting Software.exe”*.

Starting the DSS

Connecting the nutrunner






Fig. 39: Start display

3. ➤ Connect the nutrunner to the programming adapter. To this end, slide the programming adapter onto the nutrunner instead of the battery.
 - ⇒ The “Interface” list and all controls required for communication with the battery nutrunner are activated.
 - All controls that require a machine connection are deactivated (grey).
4. ➤ Select the interface to which the USB programming adapter is connected.



If the automatic COM selection is not working, select the correct COM Port manually.



5. ➤ Press Reload data from tool.
6. ➤ Press and hold the trigger until the *“Now Connected”* message is displayed.
 - ⇒ The nutrunner is connected to the terminal device via the programming adapter.



Transferring nutrunner data

Reload data from tool

7. ➔ Press Reload data from tool.

Press and hold the trigger until the *“Info: Communication successful. Settings could be changed”* message is displayed.

⇒ All available nutrunner data is loaded and displayed.

10.2 Getting to know the DSS

Start display




Fig. 40: Start display

DSS starts up in the *“Customizing”* menu.

Inactive features and data that has not yet loaded are greyed out.

The following is displayed:

- *“Machine constants”*
Parameters for the nutrunner
- *“Settings”*
Step blocking
- *“Interface”*
- *“Reset operations”*
- *“Notification”*
- *“Output”*

DSS menus

- *“Customizing”*
- *“Tool diagnostic”*
- *“Settings”*
- *“Help”*

Error messages

Error messages can be displayed in the *“Notification”* line.


🔗 *Chapter 12.2 “DSS – Error messages” on page 77*

Exiting the DSS



➔ To exit the DSS, press .

10.3 Customizing



➔ Call up the “Customizing” menu.

Retrieving nutrunner data



➔ Press .

Prerequisite:

Nutrunner is connected to DSS ➔ *Chapter 10.1 “Connecting to the DSS” on page 63.*

Press and hold the trigger until the “Info: Communication successful. Settings could be changed.” message is displayed.

⇒ All available machine data for the nutrunner is loaded and displayed:

- Serial number
- Type
- Firmware version
- ESN motor
- Last programming
- Step blocking




Fig. 41: Information

Blocking torque levels

Individual setting levels for the nutrunner can be blocked. This means it is no longer possible to use the blocked torque levels.



The breakaway torque level is blocked in “Direction tighten” (CW) as standard.




Fig. 42: Blocking torque levels

The display and setting options for step blocking is dependent on the (firmware) version of the nutrunner:

No direction of rotation recognition is possible in version 1. The blocked setting levels are blocked for both directions of rotation CW and CCW.

No gear recognition is possible in version 2. The blocked setting levels are blocked in all gears.

In version 3 (Fig. 41), each individual setting level can be blocked or enabled independently of the direction of rotation and independently of the gear setting.



1. Ensure that the nutrunner is connected to the DSS and that the nutrunner data has been retrieved.
2. Select or deselect setting levels individually. Press the corresponding number to do so.

⇒ Torque levels shown in red are blocked.

Torque levels shown in green are enabled for use.

is displayed for each change.

A message appears: *“Info: The change will not be transferred to the machine until programming.”*

3. To reset individual changes to the default values, press


.

4. Press .

5. Press and hold the trigger until the *“Info: Programming successful.”* is displayed.

⇒ The changes to the step blocking have been transferred to the nutrunner.

Saving settings and diagnostic data as a PDF



The currently displayed settings and diagnostic data can be saved as a PDF for documentation purposes and for subsequent evaluation.

1. To generate a PDF file, press .




Fig. 43: Example, PDF file

2. Specify a storage location and confirm with "Save".

⇒ If saved successfully, the "Info: Values archived successfully." message appears.

If not saved successfully, the "Error 0x01: Error during archiving." message appears.

Save settings and diagnostic to pdf

Save settings and diagnostic to pdf

10.4 Tool diagnostic

Customizing | Tool diagnostic | Settings | Help

Call up the "Tool diagnostic" menu.




Fig. 44: Tool diagnostic



Retrieving nutrunner data

Prerequisite:

Nutrunner is connected to DSS ↗ *Chapter 10.1 “Connecting to the DSS” on page 63.*




→ Press Reload data from tool.

Press and hold the trigger until the “*Info: Communication successful. Settings could be changed.*” message is displayed.

Diagnostic data	Meaning
Maximum temperature	Maximum temperature measured at the drive motor in °C. At maximum 100°C, the integrated overheating protection switches off the drive motor.
Long time overcurrent	Number of nutrunner stops due to overheating.
Switch-on counter	Number of nutrunner starts, independently of direction of rotation, runtime and result.
OK fastening cycles overall	Total number of correctly completed bolting processes with the set torques.
OK fastening cycles per setting	Number of correctly completed bolting processes with the set torques. Each individual setting level is logged separately; gears and directions are not individually separated. Save the PDF file for a detailed listing.

Saving settings and diagnostic data as a PDF

The currently displayed settings and diagnostic data can be saved as a PDF for documentation purposes and for subsequent evaluation.



→ ↗ “*Saving settings and diagnostic data as a PDF*” on page 67.

10.5 Settings



➔ Call up the “Settings” menu.





Fig. 45: Settings

Changing the language setting



The programme interface can be displayed in German and English.

➔ Select the desired language.

⇒ The programme starts with the selected language interface.

The nutrunner data needs to be reloaded.

Updating the firmware

The firmware of the nutrunner can be updated using an original PLARAD[®] configuration file.



NOTICE!

Property damage due to incorrect configuration file!

The loading of an incorrect configuration file can cause unpredictable behaviour including the destruction of the nutrunner.

- Always contact PLARAD[®] service first.
- Use only the original PLARAD[®] configuration file provided by PLARAD[®] directly.



1. ➔ Ensure that an up-to-date original PLARAD[®] configuration file is available.



Reload data from tool

2. ➤ To select the configuration file, press . Make sure it is the correct version.
3. ➤ In the subsequent selection dialogue, change to the storage location and select the correct Hex file.
4. ➤ Change to the “Customizing” or “Tool diagnostic” menu.
5. ➤ Press .

Press and hold the trigger until the firmware dialogue is displayed.

⇒ Information about the current version and any available newer version are displayed.

6. ➤



The old firmware cannot be restored after an update.





To update the firmware, press “Update”.

To abort the process, press “Cancel”.

⇒ “Update”: Message indicates the charge status. The information about the nutrunner is displayed once the firmware has been fully updated. All values are retained.

“Cancel”: No updates are performed.

10.6 Help



1. ➤ Call up the “Help” menu.

2. ➤ To view the user manual for the nutrunner, press .

⇒ The PDF file of the user manual opens in a PDF display programme.

3. ➤ To view information about the Diagnostic Setting Software DSS, press .

⇒ Information about the software is displayed in a dialogue window.

11 Performing maintenance

11.1 Maintenance schedule

Improperly performed maintenance tasks



WARNING!

Danger of injury from improperly performed maintenance tasks!

Improper maintenance can cause serious injuries and significant property damage.

- Ensure sufficient assembly space prior to commencing the tasks.
- Ensure that the assembly site is clean and tidy. Loosely stacked or randomly scattered components and tools may cause accidents.
- With regard to maintenance tasks, only allow “Clean nutrunner” and “Have it checked for damage” to be performed by the user.
- Have all repairs performed by the manufacturer.
- Never open the nutrunner.
- Use only PLARAD[®] original parts.

Faultless operation

The following sections describe the maintenance tasks that are required in order to ensure optimum and faultless operation of the nutrunner.

Insofar as routine checks reveal increased wear, shorten the requisite maintenance intervals according to the actual signs of wear. If you have questions about maintenance tasks and intervals, contact PLARAD[®] service.



Interval	Maintenance task	Personnel
Before and after every use	<ul style="list-style-type: none"> ■ Clean. ■ Check surfaces, warning symbols and pictograms for damage. ■ Check the power cable, power plug and fasteners of the battery charger for damage. ■ Check the impact wrench socket and spring clip for damage and correct operation. ■ Check the reaction arm and circlip for damage and correct operation. ■ Check for leaks. 	User
Every 3 months <ul style="list-style-type: none"> ■ In the event of extreme operating conditions (e.g. dust, dirt) ■ In the event of high frequency of use, multi-shift operation ■ In the event of constant work in the upper torque range 	<ul style="list-style-type: none"> ■ Drive motor Perform service as stipulated by the motor manufacturer. ■ Perform the software update. ■ Planetary gearbox Perform service as stipulated by the manufacturer. Lubricate. ■ Nutrunner Exchange damaged markings. Recalibrate. ■ Accessories Check for damage; exchange. ■ Exchange damaged markings. <p>🔗 Chapter 11.3 "Having service tasks performed by the manufacturer" on page 75</p>	PLARAD [®] service
Every 6 months <ul style="list-style-type: none"> ■ In the event of standard operating conditions ■ In the event of average frequency of use ■ In the event of work in the medium torque range 		
Every 12 months <ul style="list-style-type: none"> ■ In the event of low frequency of use ■ In the event of work in the low torque range 		

Accessories, spare parts and wear parts

Spare parts must meet the technical requirements specified by PLARAD[®]. This is always ensured by original spare parts. A warranty can only be provided for original spare parts supplied by PLARAD[®].

The installation or use of other spare parts can, under certain circumstances, adversely alter the specified design properties and, consequently, impair active or passive safety.

Any liability and warranty for damage resulting from the use of parts other than the original spare parts and accessory parts is excluded.

Have at least the following information about the nutrunner to hand to enable quick and easy processing:

- Client
- Serial number of the nutrunner

- Desired spare part
- Desired quantity
- Desired mode of shipping

🔗 “PLARAD[®] service” on page 4

11.2 Having the nutrunner maintained by the user

Personnel: User

Perform the following maintenance steps before and after every use:

Cleaning

1. ➤



NOTICE!

Property damage due to improper cleaning!

Clean the nutrunner with a soft cloth. Never use strong cleaning agents, water, brushes, sharp-edged tools or high-pressure cleaners.

Surfaces and markings

2. ➤

Check surfaces and markings for damage. Arrange for repairs if there is damage or illegible markings.

Battery charger

3. ➤

Check the power cable and power plug for damage and insufficient fastening. Arrange for exchange if there is damage.

Impact wrench socket

4. ➤

Check the impact wrench socket and spring clip for damage, deformation and correct operation. Arrange for exchange if there is damage.

Reaction arm

5. ➤

Check the reaction arm for damage and deformation. Check the circlip for correct operation. Arrange for exchange if there is damage.

6. ➤



WARNING!

Danger of injury due to faulty nutrunner!

Do not use a faulty nutrunner. This also applies if there are leaks. Have it repaired immediately or have the faulty parts exchanged. Contact PLARAD[®] service.

Transport case

7. ➤

Store the cleaned and damage-free nutrunner in the transport case until its next use.



11.3 Having service tasks performed by the manufacturer

Service intervals

The service intervals are dependent on the conditions of use and the operating site.

Service interval	Conditions
Every 3 months	<ul style="list-style-type: none"> ■ In the event of extreme operating conditions (e.g. dust, dirt) ■ In the event of high frequency of use, multi-shift operation ■ In the event of constant work in the upper torque range
Every 6 months	<ul style="list-style-type: none"> ■ In the event of standard operating conditions ■ In the event of average frequency of use ■ In the event of work in the medium torque range
Every 12 months	<ul style="list-style-type: none"> ■ In the event of low frequency of use ■ In the event of work in the low torque range

Contacting service



WARNING!

Danger of injury and property damage due to improperly performed service tasks!

Improperly performed service tasks can cause incorrect applications, destruction of the nutrunner and injuries.

- Do not perform service tasks yourself.

→ Contact PLARAD[®] service in good time regarding the following service tasks.

Service tasks

Personnel: ■ PLARAD[®] service

Component	Service task
Drive motor	Perform service in accordance with the manufacturer's specifications.
	Perform the software update.
Planetary gearbox	Perform service as stipulated by the manufacturer.
	Lubricate.
Accessories	Check for damage; exchange.
	Exchange damaged markings.
Nutrunner	Exchange damaged markings.
	Recalibrate.

12 Troubleshooting

12.1 Identifying faults

Malfunctions and faults can become noticeable in different ways:

- Nutrunner is not working for no apparent reason:
First note the list of typical errors and issues ↪ “FAQs” on page 76.
- Nutrunner, battery or accessory is faulty or shows signs of damage.
Contact ↪ “PLARAD[®] service” on page 4.

FAQs

Below is a summary of typical malfunctions, issues and answers. This is intended to provide rapid assistance. For problems that cannot be solved in this way, contact ↪ “PLARAD[®] service” on page 4.

Fault symptom	Measure
The nutrunner will not start.	Check the battery charge status and charge or replace the battery in the event of insufficient charge. Is the torque level blocked? ↪ Chapter 10 “Using the Diagnostic Setting Software DSS” on page 62
The device gets hot too quickly.	Are the openings for the air supply dirty or clogged? Clean with a soft cloth.
Battery charge status indicator is flashing red.	The battery is not operational. Bring the battery to within the operating temperature range and then charge it.
Battery charge status indicator lights up red continuously.	The battery is empty. Charge the battery.
An acoustic signal sounds.	Is the torque level blocked? ↪ Chapter 10 “Using the Diagnostic Setting Software DSS” on page 62
Two brief acoustic signals during use.	The bolting process was not successful. The set torque was not reached. Determine the bolting process. Repeat tightening.



12.2 DSS – Error messages

Error messages in the “*Notification*” line:

Error number	Message	Meaning
01	No connection to the tool. Press power switch	Nutrunner cannot be connected. It is potentially not connected. Check the COM-Port connection.
	The tool sends none or no correct data	The update was not completed or was not fully completed. The firmware could be damaged. Repeat the update.
	Timeout on dump	Nutrunner did not transmit the correct data. Restart the DSS.
	Timeout on dump request	Nutrunner did not transmit any data. Restart the DSS.
	Syntax within HEX-file - Firmware not changed	Internal error. The firmware has not yet changed. Repeat the update.
	Checksum transfer - Firmware not changed	Transmission error. The firmware has not yet changed. Repeat the update.
	Timeout transfer - Firmware not changed	Internal error. The firmware has not yet changed. Repeat the update.
	Syntax within HEX-file - Firmware corrupted	Internal error. The original software is potentially damaged. Repeat the update.
	Checksum transfer - Firmware corrupted	Transmission error. The original software is potentially damaged. Repeat the update.
	Checksum FRAM - Firmware corrupted	FLASH error. The original software is potentially damaged. Repeat the update.
	Timeout transfer - Firmware corrupted	Transmission error. The original software is potentially damaged. Repeat the update.
21, 22, 23	Serial Port timed out	No connection to the programming adapter. The FTDI driver is potentially not installed correctly.
31	No response from the power tool	No confirmation from the device. The original software is potentially damaged. Repeat the update.

Error number	Message	Meaning
32, 33	There are several possible messages (from the operating system)	No confirmation from the device. The original software is potentially damaged. Repeat the update.
39	No valid response	No valid confirmation from the electronic device. The original software is potentially damaged. Repeat the update.
41	Serial Port read timed out	No connection to the programming adapter. The FTDI driver is potentially not installed correctly.
42	Serial Port IO-Exception	No connection to the programming adapter. The FTDI driver is potentially not installed correctly.
43	Serial Port already open	No connection to the programming adapter. The FTDI driver is potentially not installed correctly.
44	Serial Port not open	No connection to the programming adapter. The FTDI driver is potentially not installed correctly.
51, 53	There are several possible messages (from the operating system)	The terminal device detects an error during reception of the serial data.

12.3 Performing troubleshooting

Improperly performed troubleshooting



WARNING!

Danger of injury due to improperly performed troubleshooting!

Improper troubleshooting can cause serious injuries and significant property damage.

- The user may only clean the nutrunner and check it for damage.
- Have all repairs performed by the manufacturer.
- Never open the nutrunner.
- Use only PLARAD[®] original parts.

Device damage

→ Contact  “PLARAD[®] service” on page 4 if there is any damage to the nutrunner.



Battery

- Replace a faulty or uncharged battery. Do not put faulty batteries into service.



Reorder battery:

Contact PLARAD[®] service.

Returning to service after repair



WARNING!

Danger of injury due to faulty nutrunner!

If a nutrunner is not properly repaired, this can cause serious injuries.

- Never put a defective nutrunner back into service.

- Check for correct operation prior to first-time use.

13 Disposing of the nutrunner

The nutrunner must be disposed of in an environmentally sound manner at the end of its service life.

Disassembly



WARNING!

Danger of injury due to short circuit and stored residual energy!

If components are damaged, there is a danger of injury due to short circuit or the continued presence of stored residual energy.

1. ➤ Disconnect the battery from the nutrunner.
2. ➤ Remove the impact wrench socket, reaction arm and all other optional attachment parts.
⇒ Reuse these components if necessary.
3. ➤ Do not dismantle the nutrunner any further.

Disposal

Insofar as no take-back or disposal agreement has been put in place, dispose of the nutrunner as electronic waste in accordance with local regulations. Use authorised collection points for the reprocessing of old electrical and electronic devices.



ENVIRONMENT!

Danger to the environment due to incorrect disposal!

Incorrect disposal can be hazardous to the environment.



Do not allow electronic components to enter bodies of water, the sewage system, the soil or household waste collection.

Have electronic waste, electronic components, lubricants and other auxiliary materials disposed of by approved specialist companies.



Do not dispose of battery cells and button cells in household waste.

Dispose of the plastic transport case and foam inlay separately from the nutrunner.

If in doubt, obtain information about environmentally sound disposal from the local municipal authority or from specialist disposal companies.



14 Technical data

Dimensions and weight

Data	Value	Unit
Weight*	5.1	kg
Length	365	mm
Width	68	mm
Height	245	mm

* Specific details on the rating plate. Specifications without reaction arm but with battery.

Performance values

Data	Value	Unit
Performance range	See torque chart	
Speed	up to 99	min ⁻¹

Electrical connected loads

Data	Value	Unit
Battery charger nominal input voltage, 50 to 60 Hz	220 to 240	V
Battery charger nominal input voltage, 50 to 60 Hz	100 to 120	V
Battery charger power consumption, maximum	100	W
Battery charger charging current, maximum	5,000	mA
Nominal battery voltage	18	V
Battery capacity	5.2 – 6	Ah
Battery	Lithium-ion	
Protective insulation	Protection class IP20	

Environment

Data	Value	Unit
Temperature range	0 to 50	°C
Temperature range for charger, battery	5 to 45	°C

Emissions

Emission levels as per EN 60745

Data	Value	Unit
Emission sound power level L_{WA}	82	dB(A)
Emission sound pressure level L_{pA}	72	dB(A)
Measurement uncertainty of emission sound pressure level	3	dB(A)
Vibration total value	< 2.5	m/s ²
Measurement uncertainty for vibration total value	1.5	m/s ²



15 Index

A

Accessories	20
Authorised partners	4
Automatic release function	20
Automatic safety swivel joint	19

B

Battery	
Care	50
Care rules	50
Charger	12
Charging	52
Connecting to the nutrunner	53
Deep discharge	51
Disposing	80
Illustration	12
LED display for battery charger	18
Memory effect	51
not in use for a prolonged period of time	50
Release button	17
Self-discharge	51
Service life	51
Storing	50
Temperature range	51
Battery charge status	
LEDs on the battery	17
Proactive display	16
Query button on the battery	17
Bracing the DA2motion reaction arm	55
Breakaway torque level	54
Brief description	12
Button cell	80

C

Case	7
Claw adapter	11
Cleaning	74
Connected loads	81
Controls	14
Copyright	3

Customer service	4, 43
Customizing	66

D

DA2motion	
Accessories	21
Illustration	10
Illustration of reaction arm	11
Moving fittings	58
Preparing	47
Reaction arm	18
Revolution counter	18
Using the reaction arm	55
Delivery	7
Checking	7
Packaging material	8
Determining the application	46
Diagnostic Setting Software	62
Direction of rotation setting	15
Disassembly	80
Displaying programme information	71
Displaying the user manual	71
Disposal	80
Disposing of the battery	80
DSS	62
Blocking torque levels	66
Connecting	63
Customizing	66
Error messages	77
Help	71
Installing	63
Retrieving nutrunner data	66
Saving as a PDF	67
Scope of delivery	62
Settings	70
Tool diagnostic	69

E

Electrical current	32
Electronic waste	80

Emissions	82	Manufacturer	4
Environmental protection	45	Maschinenfabrik Wagner	4
Electrical and electronic components	45	Memory effect	51
Lubricants	45	Misuse	27
Rechargeable batteries and batteries	45		
Extension	11	N	
F		Noise emissions	82
FAQ	76	Nutrunner	
Faults	76	Disposing	80
Foam inlay	7	Getting to know	10
Functions		Maintaining	72
Overview	19	Troubleshooting	76
		Unpacking	7
		Using it safely	22
G		O	
Gear setting	15, 54	Old devices	80
Ground	11	Open and close fittings	58
H		Operating conditions	81
Handle	16	Operator	43
Help	43	Operator's obligations	41
I		Ordering spare parts	73
Illustration	10	Other applicable documents	3
Battery	12	P	
DA2 <i>motion</i>	10	Packaging material	8
Inlay	7	Performance values	81
Installation	63	Performance variables	13
Intended use	27	Personal protective equipment	43
L		Personnel	42
Lazy battery effect	51	Personnel qualifications	42
M		PLARAD customer service	43
Maintenance	72	PLARAD service	43
Cleaning	74	PPE	43
Manufacturer	75	Protection class II	26
Overview	72	Q	
User	74	Qualified nutrunner personnel	42
Maintenance schedule	72	R	
Malfunctions	76	Rating plate	13
Identifying	76	Reaction arm of DA2 <i>motion</i>	18
Manual adapter	11	Release function	20

Residual risks	31	Setting levels	15, 54
Antenna	34	Setting the torque levels	54
Battery	34	Signs	24
Bracing	36	Software	
Breakage	36	DSS	62
Button cell	34	Stickers	24
Crushing	36	Suggestion for improvement	4
Ejecting	35	Symbols	
Electric shock	32	In the manual	22
Electrical energy	32	On the nutrunner	24
EMC	34	T	
End-of-life electric/electronic device	34	Technical data	81
Hot surfaces	38	Telescopic adapter	11
Interfering radiation	34	Tool diagnostic	69
Lithium	34	Torque selection diagram	
Moving components	35	DA2 <i>motion</i> 05	6
Noise	38	DA2 <i>motion</i> 10	6
Overloading	36	Transport position	15
Radiation	34	Trigger	17
Rotational movements	35	Troubleshooting	
Spare parts	36	Performing	78
Transmitter	34	U	
Weight	36	Unauthorised persons	43
Revolution counter	18	Unpacking	7
S		User	42
Safety	22	User requirements	42
Safety devices	40	W	
Safety swivel joint	19	Who can I ask?	43
Service	4, 43		
Service tasks	75		

Appendix




The following documents are supplied with the nutrunner in a document folder in addition to this manual.

- EU declaration of conformity
- USB stick
- Torque selection diagram
- Certificates (option)
- Technical data sheet

A Torque selection diagram for DA2*motion*



Drehmomentauswahldiagramm DA2motion 05




Ver. 20210325



max. Drehmoment + ca. 15% von Wert aus Potistellung 15
(Diese Einstellung nur in Ausnahmefällen verwenden)
max. torque + approx. 15% of Poti value set 15
(use this setting only in exceptional cases)



Drehmomentauswahldiagramm DA2motion 10



max. Drehmoment + ca. 15% von Wert aus Potstellung 15
 (Diese Einstellung nur in Ausnahmefällen verwenden)
 max. torque + approx. 15% of pot value set 15
 (use this setting only in exceptional cases)

Ver. 20210325